



1. REMOVE DRAWERS FROM DRAWER BOX UNIT.
2. USE BOLTS & METAL CROSS DOWELS SUPPLIED TO FASTEN FRONT & BACK RAILS BETWEEN HEAD & FOOTBOARD. (DO NOT FULLY TIGHTEN)
3. KEEP THE FRONT OF THE DRAWER BOX 3/4" BACK FROM FRONT OF SIDE RAIL.  
USE THE 1 1/2" LONG SCREWS PROVIDED THRU THE TOP FRONT RAIL INTO THE SIDERAIL CLEAT AND THRU THE BEDBOX ENDS INTO BED ENDS.
4. LAY PLATFORM DECK BETWEEN SIDE RAILS AND SCREW DOWN THRU THE DECK INTO THE SIDE RAIL CLEATS USING THE 1 3/4" FH SCREWS PROVIDED.
5. FULLY TIGHTEN BOLTS IN HEAD & FOOTBOARD AND INSTALL DRAWERS

STEP	HARDWARE REQUIRED FOR 1 BED:
2	8 - HEX DRIVE BOLTS [90mm] AND 8 - METAL CROSS DOWELS
3	8 - 1 1/2" L X #8 PH SCREWS
4	12 - 1 3/4" L X #8 FH SCREWS